

2009 FENDERTRIM APPLICATION GUIDE

PART NUMBER	APPLICATION	YEAR
DODGE		
D217-2412 D223-2407S	DAKOTA PICK UP (NO FLARES) RAM 1500/2500/3500HD DUALY WITH SIDE MOLDINGS (SHORT)	1997-04 1994-01
D250-2408L	RAM 1500/2500/3500HD DUALY WITHOUT SIDE MOLDINGS (LONG)	1994-01
D251-2420L D252-2420S	RAM 1500/2500/3500 (LONG) RAM 1500/2500/3500 (SHORT)	2002-08 2002-08
CHEVY/GMC		
C119-2205	C/K 1500/2500/3500 DUALY/STEP SIDE WITHOUT SIDE MOLDINGS	1988-99
C120-2203	C/K 1500/2500/3500 DUALY STEP SIDE WITH SIDE MOLDINGS	1988-99
C127-2212 C133-2118S	S10/BLAZER S15 JIMMY/SONOMA AVALANCHE/SILVERADO/SIERRA WITHOUT FLARES (SHORT)	1995-05 1999-06
C134-2118L	AVALANCHE/SILVERADO SIERRA (LONG)	1999-06
C145-3908 C145-3908F C146-3406N C146-3406NF	SILVERADO 1500/2500 SILVERADO DUALY FRONTS ONLY SIERRA 1500/2500 SIERRA DUALY FRONTS ONLY	2007+ 2007+ 2007+ 2007+
FORD		
F168-2601 F169-3106 F185-3112 F190-3124 F201-3125 <u>NEW</u> F202-3132 <u>NEW</u>	F150 FULL SIZE F150/FLARESIDE (WITHOUT FLARES) F250/350 SUPER DUTY F150/250/350/FLARESIDE F250/350/450 SUPER DUTY F350/450 DUALY	1987-96 1997-03 1999-07 2004-08 2008-09 2008-09